



QLD SUSTAINABLE HOUSE CODE ENERGY EFFICIENT LIGHTING

FLOURESCENT LIGHTS OR COMPACT FLOURESCENT LIGHTS (CFLs) ARE TO BE USED IN 80% OF THE TOATL AREA OF ALL ROOMS. AREA MEASURED TO INCLUDE GARAGE.

Α	DATE	DRAWN
VER	DATE	DESCRIPTION



	PROJECT
)	
)	
ô	AT:
4	

SCALE	DRAWN	DRAWING TI
1:100 at A3	A. Brind	
FOR:		UPPE

DRAWING TITLE JOB I.D.

UPPER LEVEL ELECTRICAL PLAN

DWG No	VER	
W13	Α	